

Your TimeFactor has been shipped with Version 2.0 software. The following notes supersede the User Guide. Please visit www.eventide.com to register your TimeFactor and for downloading future software updates.

Control Knobs/Effect Parameters

FeedBack

The range of the Feedback controls for all delay effects has been increased to 110%. This allows TimeFactor to go into self-oscillation at high feedback values resulting in some very interesting (and potentially LOUD) sounds. BE CAREFUL!

Looper

The Looper now responds to MIDI Start/Stop commands when MIDI clock is present.

System Menu Updates

[BYPASS] - Select Bypass Mode

[BYP TYP] - The name of Bypass Type [DSP+DLY] has been changed to [DSP+FX].

[AUX SW] - Program Auxiliary Switches

"Alternate" Aux Switch Mode

In Alternate Mode, the AUX switches act as Play Switches when the Stompbox is in Bank Mode and Bank Switches when the Stompbox is in Play Mode. The alternate mode switch designators, "FS1", "FS2" and "FS3", have been added to the AUX SW Menu.

PDL choice added to AUX SW Menu

Assigning "PDL" to an Aux Switch allows you to get the full value of the preset's Expression Pedal assignment (Toe down) while you hold that switch. This is great for things like sending feedback to 110% while holding the switch down and then back to a "safe" value when you let go.

[MIDI] - MIDI Functions

[RCV CTL] - Alternate Mode Footswitch Designators FS1, FS2, FS3

FS1, FS2, and FS3 have been added to the RCV CTL menu under MIDI in System Mode.

[RCV CTL] - Control Expression Pedal via MIDI CC

PDL has been added to the RCV CTL menu under MIDI in System Mode. This allows you to do things like automate an expression pedal performance from a computer or use an external MIDI expression pedal to control Preset expression pedal assignments.

[GLOBAL] - Global Settings

Global [MIX] [TEMPO]

Mix and Tempo now have independent Global settings in the System menu.

[UTILITY] - Utility Functions

[SPILL] - SpillOver

SpillOver provides smooth transitions when changing Presets by fading the lingering echoes of one Preset into the echoes of the next Preset. SpillOver [SPILL] can be turned ON or OFF from the Utility section of the System menu (Default is OFF.)

[BANKS] - 40 Presets. Select the Range of Active Preset Banks (1-20)

Version 2.0 doubles the available space for storing presets. There are now 20 Banks of two Presets, totaling 40 available Preset slots. Selecting BANKS in the UTILITY System Menu, you can enable a range of Banks by selecting the (L)ow and (H)igh BANK. This is useful if you are playing a gig and you know that you will only need to access a specific BANK range. TimeFactor ships with 20 unique Presets - the Presets stored in BANKs 11-20 are duplicates of BANKs 1-10. TimeFactor ships with the (H)igh BANK set to 10.